



Xerox Eligible TradeUp Products

CATEGORY	MANUFACTURER	MODEL	PROMOTION
Printer - Laser	APPLE	COLOR LASERWRITER 12/600 PS	Xerox Phaser 8860
Printer - Laser	APPLE	COLOR LASERWRITER 12/660 PS	Xerox Phaser 8860
Printer - Laser	APPLE	LASERWRITER	Xerox Phaser 8860
Printer - Laser	APPLE	LASERWRITER 12/640 PS	Xerox Phaser 8860
Printer - Laser	APPLE	LASERWRITER 16/600 PS	Xerox Phaser 8860
Printer - Laser	APPLE	LASERWRITER 4/600 PS	Xerox Phaser 8860
Printer - Laser	APPLE	LASERWRITER 8500	Xerox Phaser 8860
Printer - Laser	APPLE	LASERWRITER IIF	Xerox Phaser 8860
Printer - Laser	APPLE	LASERWRITER IIG	Xerox Phaser 8860
Printer - Laser	APPLE	LASERWRITER IINT	Xerox Phaser 8860
Printer - Laser	APPLE	LASERWRITER IINTX	Xerox Phaser 8860
Printer - Laser	APPLE	LASERWRITER IISC	Xerox Phaser 8860
Printer - Laser	APPLE	LASERWRITER PLUS	Xerox Phaser 8860
Printer - Laser	APPLE	LASERWRITER PRO 600	Xerox Phaser 8860
Printer - Laser	APPLE	LASERWRITER PRO 630	Xerox Phaser 8860
Printer - Laser	APPLE	LASERWRITER PRO 810	Xerox Phaser 8860
Printer - Laser	APPLE	LASERWRITER SELECT 300	Xerox Phaser 8860
Printer - Laser	APPLE	LASERWRITER SELECT 310	Xerox Phaser 8860
Printer - Laser	APPLE	LASERWRITER SELECT 360	Xerox Phaser 8860
Printer - Laser	APPLE	PERSONAL LASERWRITER 300	Xerox Phaser 8860
Printer - Laser	APPLE	PERSONAL LASERWRITER 320	Xerox Phaser 8860
Printer - Laser	APPLE	PERSONAL LASERWRITER LS	Xerox Phaser 8860

Printer - Laser	APPLE	PERSONAL LASERWRITER NT	Xerox Phaser 8860
Printer - Laser	APPLE	PERSONAL LASERWRITER NTR	Xerox Phaser 8860
Printer - Laser	APPLE	PERSONAL LASERWRITER SC	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 10	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 10 DPS	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 10 DV	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 10 H	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 10 I	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 10 PS	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 10 V	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 4	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 4 PS	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 4 V	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 4 VE	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 6	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 6 T	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 6 V	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 600	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 630	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 630 M	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 631	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 641	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 645	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 645 M	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 650	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 655 M	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 660	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 660 PS	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 665	Xerox Phaser 8860

Printer - Laser	BROTHER	HL- 720	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 730	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 730 DX	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 730 PLUS	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 760	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 760 PLUS	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 8	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 8 AS	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 8 D	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 8 E	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 8 EG	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 8 IID	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 8 LASER AS	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 8 PS	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 8 PSAP	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 8 QS	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 8 V	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 820	Xerox Phaser 8860
Printer - Laser	BROTHER	HL- 960	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1030	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1040	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1050	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1050 DX	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1060	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1070	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1230	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1240	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1240 DX	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1250	Xerox Phaser 8860

Printer - Laser	BROTHER	HL-1250 LT	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1260	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1270 N	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1270 NLT	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1440	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1450	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1470 N	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1650	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1650 N	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1660	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1660 E	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1660 EN	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1660 N	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1670	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1670 N	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1850	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1850 N	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1870	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-1870 N	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-2040	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-2060	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-2060 M	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-2070N	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-2400 C	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-2400 CEN	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-2400 CN	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-2460	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-2460 N	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-2460 TN	Xerox Phaser 8860

Printer - Laser	BROTHER	HL-2600 CN	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-2700CN	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-3400 CN	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-3450 CN	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-4000 CN	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-5040	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-5050	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-5050 LT	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-5070 N	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-5140	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-5150 D	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-5240	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-7050	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-7050 N	Xerox Phaser 8860
Printer - Laser	BROTHER	HL-820	Xerox Phaser 8860
Printer - Laser	BROTHER	HS-5000	Xerox Phaser 8860
Printer - Laser	BROTHER	HS-5300	Xerox Phaser 8860
Printer - Laser	BROTHER	HT-500 PS	Xerox Phaser 8860
Printer - Laser	BROTHER	WL-660	Xerox Phaser 8860
Printer - Laser	CANON	6982 T	Xerox Phaser 8860
Printer - Laser	CANON	CLBP-460 PRO	Xerox Phaser 8860
Printer - Laser	CANON	IMAGE CLASS 1100	Xerox Phaser 8860
Printer - Laser	CANON	IMAGE CLASS 400	Xerox Phaser 8860
Printer - Laser	CANON	IMAGE CLASS 4000	Xerox Phaser 8860
Printer - Laser	CANON	IMAGE CLASS 4000 E	Xerox Phaser 8860
Printer - Laser	CANON	IMAGE CLASS 4000 ED	Xerox Phaser 8860
Printer - Laser	CANON	IMAGE CLASS C2100	Xerox Phaser 8860
Printer - Laser	CANON	IMAGE CLASS C2100 CS	Xerox Phaser 8860
Printer - Laser	CANON	IMAGE CLASS C2100 PD	Xerox Phaser 8860

Printer - Laser	CANON	IMAGE CLASS D780	Xerox Phaser 8860
Printer - Laser	CANON	LASER CLASS 730I	Xerox Phaser 8860
Printer - Laser	CANON	LBP-1260	Xerox Phaser 8860
Printer - Laser	CANON	LBP-1760	Xerox Phaser 8860
Printer - Laser	CANON	LBP-1760E	Xerox Phaser 8860
Printer - Laser	CANON	LBP-1760N	Xerox Phaser 8860
Printer - Laser	CANON	LBP-1760NTE	Xerox Phaser 8860
Printer - Laser	CANON	LBP-1760RE	Xerox Phaser 8860
Printer - Laser	CANON	LBP-1760RT	Xerox Phaser 8860
Printer - Laser	CANON	LBP-1760TN	Xerox Phaser 8860
Printer - Laser	CANON	LBP-2460	Xerox Phaser 8860
Printer - Laser	CANON	LBP-2460N	Xerox Phaser 8860
Printer - Laser	CANON	LBP-2460N+	Xerox Phaser 8860
Printer - Laser	CANON	LBP-3260	Xerox Phaser 8860
Printer - Laser	CANON	LBP-360 PS	Xerox Phaser 8860
Printer - Laser	CANON	LBP-4	Xerox Phaser 8860
Printer - Laser	CANON	LBP-4+	Xerox Phaser 8860
Printer - Laser	CANON	LBP-430	Xerox Phaser 8860
Printer - Laser	CANON	LBP-430W	Xerox Phaser 8860
Printer - Laser	CANON	LBP-460	Xerox Phaser 8860
Printer - Laser	CANON	LBP-460PS	Xerox Phaser 8860
Printer - Laser	CANON	LBP-460W	Xerox Phaser 8860
Printer - Laser	CANON	LBP-465	Xerox Phaser 8860
Printer - Laser	CANON	LBP-4LITE	Xerox Phaser 8860
Printer - Laser	CANON	LBP-4SX	Xerox Phaser 8860
Printer - Laser	CANON	LBP-600NX	Xerox Phaser 8860
Printer - Laser	CANON	LBP-660	Xerox Phaser 8860
Printer - Laser	CANON	LBP-8 II	Xerox Phaser 8860
Printer - Laser	CANON	LBP-8 III	Xerox Phaser 8860

Printer - Laser	CANON	LBP-8 III+	Xerox Phaser 8860
Printer - Laser	CANON	LBP-8 IIIR	Xerox Phaser 8860
Printer - Laser	CANON	LBP-8 IIIT	Xerox Phaser 8860
Printer - Laser	CANON	LBP-8 IIR	Xerox Phaser 8860
Printer - Laser	CANON	LBP-8 IIT	Xerox Phaser 8860
Printer - Laser	CANON	LBP-800	Xerox Phaser 8860
Printer - Laser	CANON	LBP-860	Xerox Phaser 8860
Printer - Laser	CANON	LBP-8A1	Xerox Phaser 8860
Printer - Laser	CANON	LBP-8A2	Xerox Phaser 8860
Printer - Laser	CANON	LBP-8SX	Xerox Phaser 8860
Printer - Laser	CANON	LBP-BX	Xerox Phaser 8860
Printer - Laser	CANON	LBP-EX	Xerox Phaser 8860
Printer - Laser	CANON	LBP-LX	Xerox Phaser 8860
Printer - Laser	CANON	LBP-NX	Xerox Phaser 8860
Printer - Laser	CANON	LBP-PX	Xerox Phaser 8860
Printer - Laser	CANON	LBP-PX II	Xerox Phaser 8860
Printer - Laser	CANON	LBS-20	Xerox Phaser 8860
Printer - Laser	DELL	LASER 1100	Xerox Phaser 8860
Printer - Laser	DELL	LASER 1600N	Xerox Phaser 8860
Printer - Laser	DELL	LASER 1700	Xerox Phaser 8860
Printer - Laser	DELL	LASER 1700N	Xerox Phaser 8860
Printer - Laser	DELL	LASER 1710	Xerox Phaser 8860
Printer - Laser	DELL	LASER 1710N	Xerox Phaser 8860
Printer - Laser	DELL	LASER 3000CN	Xerox Phaser 8860
Printer - Laser	DELL	LASER 3100CN	Xerox Phaser 8860
Printer - Laser	DELL	LASER 5100CN	Xerox Phaser 8860
Printer - Laser	DELL	LASER 5110CN	Xerox Phaser 8860
Printer - Laser	DELL	LASER S2500	Xerox Phaser 8860
Printer - Laser	DELL	LASER S2500N	Xerox Phaser 8860

Printer - Laser	DELL	M5200	Xerox Phaser 8860
Printer - Laser	DELL	M5200N	Xerox Phaser 8860
Printer - Laser	DELL	P1500	Xerox Phaser 8860
Printer - Laser	DELL	W5300	Xerox Phaser 8860
Printer - Laser	EPSON	ACTIONLASER	Xerox Phaser 8860
Printer - Laser	EPSON	ACTIONLASER II	Xerox Phaser 8860
Printer - Laser	EPSON	ACTIONLASER +	Xerox Phaser 8860
Printer - Laser	EPSON	ACTIONLASER 1000	Xerox Phaser 8860
Printer - Laser	EPSON	ACTIONLASER 1100	Xerox Phaser 8860
Printer - Laser	EPSON	ACTIONLASER 1400	Xerox Phaser 8860
Printer - Laser	EPSON	ACTIONLASER 1500	Xerox Phaser 8860
Printer - Laser	EPSON	ACTIONLASER 1600	Xerox Phaser 8860
Printer - Laser	EPSON	ACULASER C 8500	Xerox Phaser 8860
Printer - Laser	EPSON	ACULASER C1000N	Xerox Phaser 8860
Printer - Laser	EPSON	ACULASER C1900	Xerox Phaser 8860
Printer - Laser	EPSON	ACULASER C1900D	Xerox Phaser 8860
Printer - Laser	EPSON	ACULASER C1900PS	Xerox Phaser 8860
Printer - Laser	EPSON	ACULASER C1900S	Xerox Phaser 8860
Printer - Laser	EPSON	ACULASER C2000	Xerox Phaser 8860
Printer - Laser	EPSON	ACULASER C2000PS	Xerox Phaser 8860
Printer - Laser	EPSON	ACULASER C4000	Xerox Phaser 8860
Printer - Laser	EPSON	ACULASER C4000PS	Xerox Phaser 8860
Printer - Laser	EPSON	ACULASER C4000T	Xerox Phaser 8860
Printer - Laser	EPSON	ACULASER C8000	Xerox Phaser 8860
Printer - Laser	EPSON	ACULASER C8500	Xerox Phaser 8860
Printer - Laser	EPSON	ACULASER C8500DT	Xerox Phaser 8860
Printer - Laser	EPSON	ACULASER C8500PS	Xerox Phaser 8860
Printer - Laser	EPSON	ACULASER C8500PSDT	Xerox Phaser 8860
Printer - Laser	EPSON	ACULASER C8600	Xerox Phaser 8860

Printer - Laser	EPSON	ACULASER C8600PS	Xerox Phaser 8860
Printer - Laser	EPSON	ACULASER C900	Xerox Phaser 8860
Printer - Laser	EPSON	ACULASER C900N	Xerox Phaser 8860
Printer - Laser	EPSON	COLORPAGE 8000	Xerox Phaser 8860
Printer - Laser	EPSON	DFX 8500	Xerox Phaser 8860
Printer - Laser	EPSON	ELP N1600	Xerox Phaser 8860
Printer - Laser	EPSON	ELP N2050	Xerox Phaser 8860
Printer - Laser	EPSON	ELP-5700 I	Xerox Phaser 8860
Printer - Laser	EPSON	ELP-5700 L	Xerox Phaser 8860
Printer - Laser	EPSON	ELP-5800	Xerox Phaser 8860
Printer - Laser	EPSON	EPL 2750	Xerox Phaser 8860
Printer - Laser	EPSON	EPL 2750DT	Xerox Phaser 8860
Printer - Laser	EPSON	EPL 5700	Xerox Phaser 8860
Printer - Laser	EPSON	EPL 5700I	Xerox Phaser 8860
Printer - Laser	EPSON	EPL 5700L	Xerox Phaser 8860
Printer - Laser	EPSON	EPL 5700PTX	Xerox Phaser 8860
Printer - Laser	EPSON	EPL 5800	Xerox Phaser 8860
Printer - Laser	EPSON	EPL 5900	Xerox Phaser 8860
Printer - Laser	EPSON	EPL 5900L	Xerox Phaser 8860
Printer - Laser	EPSON	EPL 5900N	Xerox Phaser 8860
Printer - Laser	EPSON	EPL 5900PS	Xerox Phaser 8860
Printer - Laser	EPSON	EPL 6100L	Xerox Phaser 8860
Printer - Laser	EPSON	EPL 6100N	Xerox Phaser 8860
Printer - Laser	EPSON	EPL 6100PS	Xerox Phaser 8860
Printer - Laser	EPSON	EPL 6200	Xerox Phaser 8860
Printer - Laser	EPSON	EPL 6200L	Xerox Phaser 8860
Printer - Laser	EPSON	EPL N 2750PS	Xerox Phaser 8860
Printer - Laser	EPSON	EPL N1200	Xerox Phaser 8860
Printer - Laser	EPSON	EPL N1600	Xerox Phaser 8860

Printer - Laser	EPSON	EPL N1600PS	Xerox Phaser 8860
Printer - Laser	EPSON	EPL N2000	Xerox Phaser 8860
Printer - Laser	EPSON	EPL N2050	Xerox Phaser 8860
Printer - Laser	EPSON	EPL N2050D+	Xerox Phaser 8860
Printer - Laser	EPSON	EPL N2050DT+	Xerox Phaser 8860
Printer - Laser	EPSON	EPL N2050PS+	Xerox Phaser 8860
Printer - Laser	EPSON	EPL N2700/PS3	Xerox Phaser 8860
Printer - Laser	EPSON	EPL N2750	Xerox Phaser 8860
Printer - Laser	EPSON	EPL-6000	Xerox Phaser 8860
Printer - Laser	EPSON	EPL-7000	Xerox Phaser 8860
Printer - Laser	EPSON	EPL-7500	Xerox Phaser 8860
Printer - Laser	EPSON	EPL-8000	Xerox Phaser 8860
Printer - Laser	EPSON	EPL-N1200	Xerox Phaser 8860
Printer - Laser	EPSON	EPL-N2000	Xerox Phaser 8860
Printer - Laser	EPSON	GQ-3500	Xerox Phaser 8860
Printer - Laser	EPSON	MICROLASER POWERPRO WIN/4	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET (C3100A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 1500 (Q2489A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 1500L (Q2488A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 1500LXI	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 1600	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 2500 (C9706A#ABA)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 2500L (C9705A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 2500LN	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 2500N (C9707A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 2500TN (C9708A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 2550	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 2550L	Xerox Phaser 8860

Printer - Laser	HP	COLOR LASERJET 2550LN	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 2550N	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 2605DN	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 2605DTN	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 3000DN	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 3000N	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 3500	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 3500N	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 3550	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 3550N	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 3600DN	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 3600N	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 3700	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 3700DN	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 3700DTN	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 3700N	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 3800	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 3800DN	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 3800DTN	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 3800N	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 4500 (C4084A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 4500DN (C4094A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 4500N (C4089A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 4550 (C7085A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 4550DN (C7087A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 4550HDN (C7088A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 4550N (C7086A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 4600 (C9660A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 4600DN (C9661A)	Xerox Phaser 8860

Printer - Laser	HP	COLOR LASERJET 4600DTN (C9662A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 4600HDN (C9663A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 4600N (C9692A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 4610	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 4650	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 4650DN	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 4650DTN	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 4650HDN	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 4650N	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 4700	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 4700DN	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 4700DTN	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 4700N	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 4700PH+	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 5 (C3961A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 5500 (C9656A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 5500DN (C9657A#483)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 5500DTN	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 5500HDN (C9659A#483)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 5500HDN (C9659A#ABA)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 5500N (C7131A#483)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 5500N (C7131A#ABM)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 5550	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 5550DN	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 5550DTN	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 5550HDN	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 5550N	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 5M (C3962A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 5N	Xerox Phaser 8860

Printer - Laser	HP	COLOR LASERJET 8500 (C3983A#ABA)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 8500DN	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 8500N	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 8550 (C7096A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 8550DN (C7098A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 8550GN (C7099A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 8550MFP	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 8550N (C7097A)	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 9500HDN	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET 9500N	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET CP3505	Xerox Phaser 8860
Printer - Laser	HP	COLOR LASERJET CP4005	Xerox Phaser 8860
Printer - Laser	HP	D640 (C5620A)	Xerox Phaser 8860
Printer - Laser	HP	D640 (C5620B)	Xerox Phaser 8860
Printer - Laser	HP	LaserJet	Xerox Phaser 8860
Printer - Laser	HP	LASERJET	Xerox Phaser 8860
Printer - Laser	HP	LASERJET (C7058A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET +	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1000 (Q1342A#ABA)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1000W (Q1342A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1005W	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1010	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1012	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1015	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1018	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1020	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1022	Xerox Phaser 8860
Printer - Laser	HP	LaserJet 1022N	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1100 (C4224A)	Xerox Phaser 8860

Printer - Laser	HP	LASERJET 1100A (C4219A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1100A SE (C4220A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1100ASE	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1100AXI	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1100SE (C4226A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1100XI (C4225A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1150 (Q1336A#ABY)	Xerox Phaser 8860
Printer - Laser	HP	LaserJet 1160	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1160LE	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1200 (C7044A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1200N (C7048A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1200SE (C7047A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1220	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1220SE	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1220SE (C7049A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1300 (Q1334A#ABA)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1300N (Q1335A#ABA)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1300XI	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1320	Xerox Phaser 8860
Printer - Laser	HP	LaserJet 1320n	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1320NW	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 1320TN	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2100 (C4170A#ABA)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2100 (C4170A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2100 XI (C4139A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2100M (C4171A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2100N	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2100SE (C4138A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2100TN (C4172A)	Xerox Phaser 8860

Printer - Laser	HP	LASERJET 2100XI	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2200 (C7064A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2200D (C7058A#201)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2200DN (C7063A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2200DSE (C7062A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2200DT (C7059A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2200DTN (C7061A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2300 (Q2472A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2300D (Q2474A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2300DN (Q2475A#201)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2300DTN	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2300L (Q2477A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2300N (Q2473A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2300TN	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2420	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2420D	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2420DN	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2430	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2430DTN	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2430N	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2430TN	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 2600N	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 3015	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 3020	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 3100	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 3100SE (C4175A#ABA)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 3100XI (C4177A#ABA)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 3150	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 3150SE	Xerox Phaser 8860

Printer - Laser	HP	LASERJET 3150XI	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 3200	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 3200M	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 3200SE	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 3200SE (C7053A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 3310	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 3320	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 3380	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4 (C2001A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4+ (C2037A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4000 (C4118A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4000N (C4120A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4000SE (C3094A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4000T (C4119A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4000TN (C4121A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4050 (C4251A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4050 (C4251A,C4127A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4050 (C7829B)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4050N (C4253A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4050SE (C4255A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4050T	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4050T (C4252A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4050TN (C4254A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4050USB-MAC	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4100 (C8049A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4100DTN (C8052A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4100N (C8050A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4100N (C9165A)	Xerox Phaser 8860

Printer - Laser	HP	LASERJET 4100TN (C8051A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4100TN (C9166A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4200 (Q2425A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4200DTN (Q2428A#ABA)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4200DTNS (Q2446A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4200DTNSL (Q2447A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4200N (Q2426A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4200TN (Q2427A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4240N	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4250	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4250DTN	Xerox Phaser 8860
Printer - Laser	HP	LaserJet 4250dtnsL	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4250N	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4250TN	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4300 (Q2431A#ABA)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4300DTN (Q2434A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4300DTNS	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4300DTNSL (Q2448A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4300N (Q2432A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4300TN (Q2433A#ABA)	Xerox Phaser 8860
Printer - Laser	HP	LaserJet 4345xm	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4350	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4350DTN	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4350DTNSL	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4350N	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4350TN	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4L	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4L (C2003A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4L PRO	Xerox Phaser 8860

Printer - Laser	HP	LASERJET 4LC	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4M	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4M+ (C2039A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4ML	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4MP	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4MV	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4MV (C3142A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4P (C2005A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4SI (C2009A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4SIMX	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 4V	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5 (C3916A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5 (C3916AR)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 500+	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5000 (C4100A#ABA)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5000DN (C8068A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5000GN (C4112A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5000N (C4111A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5100 (Q1860A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5100DTN (Q1862A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5100TN (Q1861A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5200	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5200DTN	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5200TN	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5L (C3941A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5L XTRA	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5L-FS	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5M (C3917A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5MP (C3155A)	Xerox Phaser 8860

Printer - Laser	HP	LASERJET 5N (C3095A#ABH)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5N (C3952A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5P (C3150A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5P (LJ5P)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5SE (C3082A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5SI (C3166A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5SI MOPIER (C4176A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5SI MOPIER (C4176AKS)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5SI MX (C3167A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5SI NX (C3950A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5SIHM	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5SIMOPIER (C4076A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5SIMX	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 5SINX	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 6L (C3990A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 6LSE (C3994A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 6LXI (C3996A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 6MP (C3982A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 6P (C3980A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 6PSE (C4212A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 6PXI (C4213A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 8000 (C4085A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 8000 DN (C4087A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 8000DN (81470)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 8000MFP (C8064A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 8000N (C4086A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 8100 (C4214A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 8100DN (C4216A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 8100MFP (C8065A)	Xerox Phaser 8860

Printer - Laser	HP	LASERJET 8100N (C4215A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 8150 (C4265A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 8150DN (C4267A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 8150HN (C4269A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 8150MFP (C4268A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 8150N (C4266A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 9000 (C8519A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 9000DN (C8521A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 9000HNF (Q3685A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 9000HNS (C8522A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 9000N (C8520A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 9040	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 9040DN	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 9040N	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 9050	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 9050DN	Xerox Phaser 8860
Printer - Laser	HP	LASERJET 9050N	Xerox Phaser 8860
Printer - Laser	HP	LASERJET II	Xerox Phaser 8860
Printer - Laser	HP	LASERJET IID	Xerox Phaser 8860
Printer - Laser	HP	LASERJET III (33449A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET IIID	Xerox Phaser 8860
Printer - Laser	HP	LASERJET IIIP (33481A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET IIISI	Xerox Phaser 8860
Printer - Laser	HP	LASERJET IIP	Xerox Phaser 8860
Printer - Laser	HP	LASERJET IIP+ (C2007A)	Xerox Phaser 8860
Printer - Laser	HP	LASERJET P2015	Xerox Phaser 8860
Printer - Laser	HP	LASERJET P3005	Xerox Phaser 8860
Printer - Laser	HP	MOPIER 240 (C4228A)	Xerox Phaser 8860
Printer - Laser	HP	MOPIER 320 W/O SCANNER (C4229A)	Xerox Phaser 8860

Printer - Laser	IBM	2770 INFORPRINT 70	Xerox Phaser 8860
Printer - Laser	IBM	3160 MADV FUNCT. PRTR	Xerox Phaser 8860
Printer - Laser	IBM	3160-INFOPRINT 60	Xerox Phaser 8860
Printer - Laser	IBM	3900 ADVANCED FUNCTION	Xerox Phaser 8860
Printer - Laser	IBM	4000 INFOPRINT ADV PRINT	Xerox Phaser 8860
Printer - Laser	IBM	4317 LSR NETWORK-17 PG	Xerox Phaser 8860
Printer - Laser	IBM	4322 INFOPRINT 21	Xerox Phaser 8860
Printer - Laser	IBM	4324 24 (LV) (MA ONLY)	Xerox Phaser 8860
Printer - Laser	IBM	4332 INFOPRINT 32 (120V)	Xerox Phaser 8860
Printer - Laser	IBM	4332 INFOPRINT 32 (120V)	Xerox Phaser 8860
Printer - Laser	IBM	4370 INFOPRINT CONT. FORMS PRINT	Xerox Phaser 8860
Printer - Laser	IBM	4370 INFOPRINT CONT. FORMS PRINT	Xerox Phaser 8860
Printer - Laser	IBM	INFOPRINT 12	Xerox Phaser 8860
Printer - Laser	KONIKA	PAGEPRO 1250	Xerox Phaser 8860
Printer - Laser	KONIKA	PAGEPRO 1250W	Xerox Phaser 8860
Printer - Laser	KONIKA	PAGEPRO 1400W	Xerox Phaser 8860
Printer - Laser	KYOCERA	CI1100	Xerox Phaser 8860
Printer - Laser	KYOCERA	DP-3600	Xerox Phaser 8860
Printer - Laser	KYOCERA	DP-560	Xerox Phaser 8860
Printer - Laser	KYOCERA	DP-580	Xerox Phaser 8860
Printer - Laser	KYOCERA	DP-650	Xerox Phaser 8860
Printer - Laser	KYOCERA	ECOSYS FS-1600 +	Xerox Phaser 8860
Printer - Laser	KYOCERA	F- 800 A	Xerox Phaser 8860
Printer - Laser	KYOCERA	F-1000 A COMPACT LP PRESCRIBE	Xerox Phaser 8860
Printer - Laser	KYOCERA	F-1010 COMPACT LP	Xerox Phaser 8860
Printer - Laser	KYOCERA	F-1800 A	Xerox Phaser 8860
Printer - Laser	KYOCERA	F-2000 A	Xerox Phaser 8860
Printer - Laser	KYOCERA	F-2010 COMPACT LP PRESCRIBE	Xerox Phaser 8860
Printer - Laser	KYOCERA	F-3000 A	Xerox Phaser 8860

Printer - Laser	KYOCERA	F-3010 COMPACT LP PRESCRIBE	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS- 400 A	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS- 600	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS- 800	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-1000	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-1000 +	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-1000 N	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-1000 T	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-1000 TN	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-1200	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-1500 A ECOSYS	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-1550 +	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-1550 A	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-1600 +	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-1600 A	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-1700	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-1700 +	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-1700 ECOSYS	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-1750	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-1800	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-1800 N	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-1800 TN	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-3400 A	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-3500 A ECOSYS	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-3500 A SYSTEM 2	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-3500 A SYSTEM 3	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-3600 +	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-3600 A	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-3700	Xerox Phaser 8860

Printer - Laser	KYOCERA	FS-3700 +	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-3750	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-3800	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-3800 N	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-3800 TN	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-5900 C	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-6700	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-7000	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-7000 +	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-9000	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-9000 EN	Xerox Phaser 8860
Printer - Laser	KYOCERA	FS-9000 N	Xerox Phaser 8860
Printer - Laser	KYOCERA	FX-1700 +	Xerox Phaser 8860
Printer - Laser	KYOCERA	FX-7000 +	Xerox Phaser 8860
Printer - Laser	KYOCERA	IPH-3500	Xerox Phaser 8860
Printer - Laser	KYOCERA	IPH-3503	Xerox Phaser 8860
Printer - Laser	KYOCERA	IPH-3503 C	Xerox Phaser 8860
Printer - Laser	KYOCERA	IPH-3504	Xerox Phaser 8860
Printer - Laser	KYOCERA	Q-8010	Xerox Phaser 8860
Printer - Laser	LEXMARK	C510	Xerox Phaser 8860
Printer - Laser	LEXMARK	C524	Xerox Phaser 8860
Printer - Laser	LEXMARK	C534	Xerox Phaser 8860
Printer - Laser	LEXMARK	C750	Xerox Phaser 8860
Printer - Laser	LEXMARK	C752	Xerox Phaser 8860
Printer - Laser	LEXMARK	C760	Xerox Phaser 8860
Printer - Laser	LEXMARK	C762	Xerox Phaser 8860
Printer - Laser	LEXMARK	C770	Xerox Phaser 8860
Printer - Laser	LEXMARK	C772	Xerox Phaser 8860
Printer - Laser	LEXMARK	C780	Xerox Phaser 8860

Printer - Laser	LEXMARK	C782	Xerox Phaser 8860
Printer - Laser	LEXMARK	C912	Xerox Phaser 8860
Printer - Laser	LEXMARK	C950	Xerox Phaser 8860
Printer - Laser	LEXMARK	E320	Xerox Phaser 8860
Printer - Laser	LEXMARK	E321	Xerox Phaser 8860
Printer - Laser	LEXMARK	E322N	Xerox Phaser 8860
Printer - Laser	LEXMARK	E323	Xerox Phaser 8860
Printer - Laser	LEXMARK	E323N	Xerox Phaser 8860
Printer - Laser	LEXMARK	E330	Xerox Phaser 8860
Printer - Laser	LEXMARK	E332N	Xerox Phaser 8860
Printer - Laser	LEXMARK	E340	Xerox Phaser 8860
Printer - Laser	LEXMARK	E342N	Xerox Phaser 8860
Printer - Laser	LEXMARK	FORMS 2481	Xerox Phaser 8860
Printer - Laser	LEXMARK	FORMS 2490	Xerox Phaser 8860
Printer - Laser	LEXMARK	FORMS 2491	Xerox Phaser 8860
Printer - Laser	LEXMARK	FORMS 4227 PLUS	Xerox Phaser 8860
Printer - Laser	LEXMARK	LEXMARK 4039 - 10P	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA C	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA C PRO	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA C710	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA C710DN	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA C710N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA C710N SOLARIS	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA C720	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA C720DN	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA C720N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA COLOR 1200	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA COLOR 1200N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA COLOR 1200N SOLARIS	Xerox Phaser 8860

Printer - Laser	LEXMARK	OPTRA COLOR 1200NL	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA COLOR 40	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA COLOR 40N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA COLOR 45	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA COLOR 45N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA COLOR 45N SOLARIS	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA E	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA E PLUS	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA E PLUS (MAC)	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA E310	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA E312	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA E312L	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA E320	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA E322	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA EP	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA IMAGE C710 SX	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA IMAGE T614 DX	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA IMAGE W810 S	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA K1220	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA K1220N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA L	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA LX	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA LX PLUS	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA LXI	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA LXI PLUS	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA LXN PLUS	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA M410	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA M410N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA M410N SOLARIS	Xerox Phaser 8860

Printer - Laser	LEXMARK	OPTRA M412	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA M412N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA M412N SOLARIS	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA N240	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA N245	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA N245 SOLARIS	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA R PLUS	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA RN PLUS	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA RT PLUS	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA S1250	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA S1250N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA S1255	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA S1255N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA S1620	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA S1620N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA S1625	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA S1625N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA S1625N SOLARIS	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA S1650	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA S1650N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA S1855	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA S1855 SOLARIS	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA S1855N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA S2420	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA S2420N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA S2450	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA S2450N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA S2455	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA S2455N	Xerox Phaser 8860

Printer - Laser	LEXMARK	OPTRA SC1275	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA SC1275N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA SC1275N SOLARIS	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA SE3455	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA SE3455N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA SE3455N SOLARIS	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA T610	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA T610N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA T610N SOLARIS	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA T612	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA T612N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA T612N SOLARIS	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA T614	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA T614N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA T614N SOLARIS	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA T614NL	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA T616	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA T616N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA T616N SOLARIS	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA W810	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA W810DN	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA W810N	Xerox Phaser 8860
Printer - Laser	LEXMARK	OPTRA W810N SOLARIS	Xerox Phaser 8860
Printer - Laser	LEXMARK	T420D	Xerox Phaser 8860
Printer - Laser	LEXMARK	T420DN	Xerox Phaser 8860
Printer - Laser	LEXMARK	T430	Xerox Phaser 8860
Printer - Laser	LEXMARK	T430D	Xerox Phaser 8860
Printer - Laser	LEXMARK	T430D	Xerox Phaser 8860
Printer - Laser	LEXMARK	T430DN	Xerox Phaser 8860

Printer - Laser	LEXMARK	T520	Xerox Phaser 8860
Printer - Laser	LEXMARK	T520D	Xerox Phaser 8860
Printer - Laser	LEXMARK	T520DN	Xerox Phaser 8860
Printer - Laser	LEXMARK	T520N	Xerox Phaser 8860
Printer - Laser	LEXMARK	T522	Xerox Phaser 8860
Printer - Laser	LEXMARK	T522DN	Xerox Phaser 8860
Printer - Laser	LEXMARK	T522N	Xerox Phaser 8860
Printer - Laser	LEXMARK	T620	Xerox Phaser 8860
Printer - Laser	LEXMARK	T620DN	Xerox Phaser 8860
Printer - Laser	LEXMARK	T620IN	Xerox Phaser 8860
Printer - Laser	LEXMARK	T620N	Xerox Phaser 8860
Printer - Laser	LEXMARK	T622	Xerox Phaser 8860
Printer - Laser	LEXMARK	T622DN	Xerox Phaser 8860
Printer - Laser	LEXMARK	T622IN	Xerox Phaser 8860
Printer - Laser	LEXMARK	T622N	Xerox Phaser 8860
Printer - Laser	LEXMARK	T630	Xerox Phaser 8860
Printer - Laser	LEXMARK	T630N	Xerox Phaser 8860
Printer - Laser	LEXMARK	T632	Xerox Phaser 8860
Printer - Laser	LEXMARK	T632DTN	Xerox Phaser 8860
Printer - Laser	LEXMARK	T640	Xerox Phaser 8860
Printer - Laser	LEXMARK	T640DN	Xerox Phaser 8860
Printer - Laser	LEXMARK	T640DTN	Xerox Phaser 8860
Printer - Laser	LEXMARK	T640N	Xerox Phaser 8860
Printer - Laser	LEXMARK	T640TN	Xerox Phaser 8860
Printer - Laser	LEXMARK	T855DN	Xerox Phaser 8860
Printer - Laser	LEXMARK	VALUEWRITER 300	Xerox Phaser 8860
Printer - Laser	LEXMARK	VALUEWRITER 600	Xerox Phaser 8860
Printer - Laser	LEXMARK	W820	Xerox Phaser 8860
Printer - Laser	LEXMARK	W820DN	Xerox Phaser 8860

Printer - Laser	LEXMARK	W820N	Xerox Phaser 8860
Printer - Laser	NEC	SUPERSCRIPT 1400	Xerox Phaser 8860
Printer - Laser	NEC	SUPERSCRIPT 870	Xerox Phaser 8860
Printer - Laser	OKIDATA	B4100	Xerox Phaser 8860
Printer - Laser	OKIDATA	B4200	Xerox Phaser 8860
Printer - Laser	OKIDATA	B4250	Xerox Phaser 8860
Printer - Laser	OKIDATA	B4300n	Xerox Phaser 8860
Printer - Laser	OKIDATA	B4350	Xerox Phaser 8860
Printer - Laser	OKIDATA	B4350n	Xerox Phaser 8860
Printer - Laser	OKIDATA	B4350nPS	Xerox Phaser 8860
Printer - Laser	OKIDATA	B4400	Xerox Phaser 8860
Printer - Laser	OKIDATA	B4400n	Xerox Phaser 8860
Printer - Laser	OKIDATA	B4600	Xerox Phaser 8860
Printer - Laser	OKIDATA	B4600n	Xerox Phaser 8860
Printer - Laser	OKIDATA	B4600nPS	Xerox Phaser 8860
Printer - Laser	OKIDATA	B6100	Xerox Phaser 8860
Printer - Laser	OKIDATA	B6100n	Xerox Phaser 8860
Printer - Laser	OKIDATA	B6200	Xerox Phaser 8860
Printer - Laser	OKIDATA	B6200n	Xerox Phaser 8860
Printer - Laser	OKIDATA	B6300	Xerox Phaser 8860
Printer - Laser	OKIDATA	B6300n	Xerox Phaser 8860
Printer - Laser	OKIDATA	B6500	Xerox Phaser 8860
Printer - Laser	OKIDATA	B6500dn	Xerox Phaser 8860
Printer - Laser	OKIDATA	B6500dtn	Xerox Phaser 8860
Printer - Laser	OKIDATA	B6500n	Xerox Phaser 8860
Printer - Laser	OKIDATA	B8300n	Xerox Phaser 8860
Printer - Laser	OKIDATA	C3200n	Xerox Phaser 8860
Printer - Laser	OKIDATA	C3400n	Xerox Phaser 8860
Printer - Laser	OKIDATA	C5100n	Xerox Phaser 8860

Printer - Laser	OKIDATA	C5150	Xerox Phaser 8860
Printer - Laser	OKIDATA	C5150n	Xerox Phaser 8860
Printer - Laser	OKIDATA	C5200n	Xerox Phaser 8860
Printer - Laser	OKIDATA	C5200ne	Xerox Phaser 8860
Printer - Laser	OKIDATA	C5300n	Xerox Phaser 8860
Printer - Laser	OKIDATA	C5400	Xerox Phaser 8860
Printer - Laser	OKIDATA	C5400dn	Xerox Phaser 8860
Printer - Laser	OKIDATA	C5400dtn	Xerox Phaser 8860
Printer - Laser	OKIDATA	C5400n	Xerox Phaser 8860
Printer - Laser	OKIDATA	C5400tn	Xerox Phaser 8860
Printer - Laser	OKIDATA	C5500n	Xerox Phaser 8860
Printer - Laser	OKIDATA	C5800Ldn	Xerox Phaser 8860
Printer - Laser	OKIDATA	C6000dn	Xerox Phaser 8860
Printer - Laser	OKIDATA	C6000n	Xerox Phaser 8860
Printer - Laser	OKIDATA	C6100dn	Xerox Phaser 8860
Printer - Laser	OKIDATA	C6100dtn	Xerox Phaser 8860
Printer - Laser	OKIDATA	C6100hdn	Xerox Phaser 8860
Printer - Laser	OKIDATA	C6100n	Xerox Phaser 8860
Printer - Laser	OKIDATA	C7200	Xerox Phaser 8860
Printer - Laser	OKIDATA	C7200 N	Xerox Phaser 8860
Printer - Laser	OKIDATA	C7200N	Xerox Phaser 8860
Printer - Laser	OKIDATA	C7300	Xerox Phaser 8860
Printer - Laser	OKIDATA	C7300dxn	Xerox Phaser 8860
Printer - Laser	OKIDATA	C7300N	Xerox Phaser 8860
Printer - Laser	OKIDATA	C7350hdn	Xerox Phaser 8860
Printer - Laser	OKIDATA	C7350n	Xerox Phaser 8860
Printer - Laser	OKIDATA	C7400 DXN	Xerox Phaser 8860
Printer - Laser	OKIDATA	C7400 N	Xerox Phaser 8860
Printer - Laser	OKIDATA	C7400DXN	Xerox Phaser 8860

Printer - Laser	OKIDATA	C7400N	Xerox Phaser 8860
Printer - Laser	OKIDATA	C7500dxn	Xerox Phaser 8860
Printer - Laser	OKIDATA	C7500n	Xerox Phaser 8860
Printer - Laser	OKIDATA	C7550hdn	Xerox Phaser 8860
Printer - Laser	OKIDATA	C7550n	Xerox Phaser 8860
Printer - Laser	OKIDATA	C9200	Xerox Phaser 8860
Printer - Laser	OKIDATA	C9200 N	Xerox Phaser 8860
Printer - Laser	OKIDATA	C9200N	Xerox Phaser 8860
Printer - Laser	OKIDATA	C9300	Xerox Phaser 8860
Printer - Laser	OKIDATA	C9300dxn	Xerox Phaser 8860
Printer - Laser	OKIDATA	C9300n	Xerox Phaser 8860
Printer - Laser	OKIDATA	C9400	Xerox Phaser 8860
Printer - Laser	OKIDATA	C9400dxn	Xerox Phaser 8860
Printer - Laser	OKIDATA	C9500dxn	Xerox Phaser 8860
Printer - Laser	OKIDATA	C9600hdn	Xerox Phaser 8860
Printer - Laser	OKIDATA	C9600n	Xerox Phaser 8860
Printer - Laser	OKIDATA	C9800hdn	Xerox Phaser 8860
Printer - Laser	OKIDATA	C9800hn	Xerox Phaser 8860
Printer - Laser	OKIDATA	LASERLINE 6 W/ADVANCED MODULE	Xerox Phaser 8860
Printer - Laser	OKIDATA	LASERLINE 6 W/BASIC MODULE	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKICOLOR 8	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKICOLOR 8 N	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKILASER 400	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKILASER 400 E	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKILASER 410 E	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKILASER 410 E/PS	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKILASER 600 E	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKILASER 610 E	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKILASER 610 E/PS	Xerox Phaser 8860

Printer - Laser	OKIDATA	OKILASER 800	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKILASER 810	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKILASER 810 E	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKILASER 810 E/PS	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKILASER 820	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKILASER 830	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKILASER 830 PLUS	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKILASER 840	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKILASER 850	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKILASER 1200	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKILASER 1200 /PS	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKILASER 1600 N	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 4 W	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 6 E	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 6 EX	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 6 W	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 8	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 8 C	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 8 CN	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 8 N NETWORK	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 8 W	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 8 Z	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 10 E	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 10 EX	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 10 I	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 10 I/N	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 12 I	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 12 I/N	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 14 E	Xerox Phaser 8860

Printer - Laser	OKIDATA	OKIPAGE 14 EX	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 14 I	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 14 I/N	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 16 N	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 18	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 18 N	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 20	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 20 DX	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 20 DXN	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 24	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 24 DX	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 24 DXN	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 24 N	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 24 TN	Xerox Phaser 8860
Printer - Laser	OKIDATA	OKIPAGE 24 X/N	Xerox Phaser 8860
Printer - Laser	PANASONIC	DP-CL18	Xerox Phaser 8860
Printer - Laser	PANASONIC	DP-CL22	Xerox Phaser 8860
Printer - Laser	PANASONIC	KX-CL400	Xerox Phaser 8860
Printer - Laser	PANASONIC	KX-CL500	Xerox Phaser 8860
Printer - Laser	PANASONIC	KX-CL500D	Xerox Phaser 8860
Printer - Laser	PANASONIC	KX-CL510	Xerox Phaser 8860
Printer - Laser	PANASONIC	KX-CL510D	Xerox Phaser 8860
Printer - Laser	PANASONIC	KX-P7100	Xerox Phaser 8860
Printer - Laser	PANASONIC	KX-P7105	Xerox Phaser 8860
Printer - Laser	PANASONIC	KX-P7110	Xerox Phaser 8860
Printer - Laser	PANASONIC	KX-P7305	Xerox Phaser 8860
Printer - Laser	PANASONIC	KX-P7310	Xerox Phaser 8860
Printer - Laser	QMS	_2001	Xerox Phaser 8860
Printer - Laser	QMS	_2425	Xerox Phaser 8860

Printer - Laser	QMS	_3260	Xerox Phaser 8860
Printer - Laser	QMS	1060 E PRINT SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	1060 E PRINT SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	1060 PRINT SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	1100L PAGEPRO	Xerox Phaser 8860
Printer - Laser	QMS	1660 E PRINT SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	1660 PRINT SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	1725 E PRINT SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	1725 PRINT SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	1725 SLS	Xerox Phaser 8860
Printer - Laser	QMS	2025 PRINT SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	2025 TURBO IMAGING SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	2060 BX PRINT SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	2060 EX PRINT SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	2060 FX	Xerox Phaser 8860
Printer - Laser	QMS	2060 FX-1	Xerox Phaser 8860
Printer - Laser	QMS	2060 FX-2	Xerox Phaser 8860
Printer - Laser	QMS	2060 GX PRINT SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	2060 IMAGE SERVER PRINT SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	2060 PM	Xerox Phaser 8860
Printer - Laser	QMS	2060 WX	Xerox Phaser 8860
Printer - Laser	QMS	2308 /S IMAGESERVER XP	Xerox Phaser 8860
Printer - Laser	QMS	2425 EX	Xerox Phaser 8860
Printer - Laser	QMS	2425 EX IMAGESERVER	Xerox Phaser 8860
Printer - Laser	QMS	2425 FX-1	Xerox Phaser 8860
Printer - Laser	QMS	2425 FX-2	Xerox Phaser 8860
Printer - Laser	QMS	2425 TURBO	Xerox Phaser 8860
Printer - Laser	QMS	2425 TURBO EX	Xerox Phaser 8860
Printer - Laser	QMS	2425 TURBO MULTI-PACS	Xerox Phaser 8860

Printer - Laser	QMS	2560 BX	Xerox Phaser 8860
Printer - Laser	QMS	2560 EX	Xerox Phaser 8860
Printer - Laser	QMS	2560 FX	Xerox Phaser 8860
Printer - Laser	QMS	3225 IMAGESERVER	Xerox Phaser 8860
Printer - Laser	QMS	3225 PRINT SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	3225 TURBO IMAGING SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	3260 EX	Xerox Phaser 8860
Printer - Laser	QMS	3260 IMAGESERVER	Xerox Phaser 8860
Printer - Laser	QMS	3260 PRINT SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	3825 IMAGESERVER	Xerox Phaser 8860
Printer - Laser	QMS	3825 PRINT SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	4032 EX	Xerox Phaser 8860
Printer - Laser	QMS	4032 IMAGESERVER	Xerox Phaser 8860
Printer - Laser	QMS	4032 PRINT SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	4060 GX PRINT SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	4060 IMAGESERVER	Xerox Phaser 8860
Printer - Laser	QMS	420 PRINT SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	4525 IMAGESERVER	Xerox Phaser 8860
Printer - Laser	QMS	6100N	Xerox Phaser 8860
Printer - Laser	QMS	860 HAMMERHEAD PRINT SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	860 PLUS PRINT SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	BIG KISS	Xerox Phaser 8860
Printer - Laser	QMS	BIG KISS II	Xerox Phaser 8860
Printer - Laser	QMS	COLORSCRIPT 100 MODEL 10	Xerox Phaser 8860
Printer - Laser	QMS	COLORSCRIPT 1000	Xerox Phaser 8860
Printer - Laser	QMS	COLORSCRIPT 210	Xerox Phaser 8860
Printer - Laser	QMS	COLORSCRIPT 230	Xerox Phaser 8860
Printer - Laser	QMS	CONCEPT WRITER	Xerox Phaser 8860
Printer - Laser	QMS	DESKLASER 600	Xerox Phaser 8860

Printer - Laser	QMS	IMAGEN 2308	Xerox Phaser 8860
Printer - Laser	QMS	IMAGEN 3308	Xerox Phaser 8860
Printer - Laser	QMS	IMAGESTATION /S	Xerox Phaser 8860
Printer - Laser	QMS	JETSCRIPT	Xerox Phaser 8860
Printer - Laser	QMS	K8	Xerox Phaser 8860
Printer - Laser	QMS	KISS	Xerox Phaser 8860
Printer - Laser	QMS	KISS PLUS W/CARD 10	Xerox Phaser 8860
Printer - Laser	QMS	KISS PLUS W/CARD 20	Xerox Phaser 8860
Printer - Laser	QMS	KISS PLUS W/CARD 30	Xerox Phaser 8860
Printer - Laser	QMS	KISS PLUS W/CARD 40	Xerox Phaser 8860
Printer - Laser	QMS	LASER GRAFIX 1200	Xerox Phaser 8860
Printer - Laser	QMS	LASER GRAFIX 1500	Xerox Phaser 8860
Printer - Laser	QMS	LASER GRAFIX 1510	Xerox Phaser 8860
Printer - Laser	QMS	LASER GRAFIX 2000	Xerox Phaser 8860
Printer - Laser	QMS	LASER GRAFIX 2015	Xerox Phaser 8860
Printer - Laser	QMS	LASER GRAFIX 2200	Xerox Phaser 8860
Printer - Laser	QMS	LASER GRAFIX 2400	Xerox Phaser 8860
Printer - Laser	QMS	LASER GRAFIX 800 C	Xerox Phaser 8860
Printer - Laser	QMS	LASER GRAFIX 820	Xerox Phaser 8860
Printer - Laser	QMS	LASERGRAFIX 800	Xerox Phaser 8860
Printer - Laser	QMS	LASERGRAFIX 800 +	Xerox Phaser 8860
Printer - Laser	QMS	LASERGRAFIX 800 II	Xerox Phaser 8860
Printer - Laser	QMS	LASERGRAFIX 810	Xerox Phaser 8860
Printer - Laser	QMS	LP 15	Xerox Phaser 8860
Printer - Laser	QMS	LPK 100	Xerox Phaser 8860
Printer - Laser	QMS	M 3000	Xerox Phaser 8860
Printer - Laser	QMS	M 3270	Xerox Phaser 8860
Printer - Laser	QMS	M 3400	Xerox Phaser 8860
Printer - Laser	QMS	M 3400 C	Xerox Phaser 8860

Printer - Laser	QMS	M 357	Xerox Phaser 8860
Printer - Laser	QMS	M 4003	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 2 CX	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 2 DESKLASER	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 2 DX	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 2 EX	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 2+ CXD	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 2+ CXE	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 2+ EXD	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 2+ GXE	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 2200 DESKLASER	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 2200 DESKLASER	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 2200 DP	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 2200 EN	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 2200 GN	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 2200 N	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 2300 EN	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 2300DL	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 2300W	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 330 CX	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 330 EX	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 330 PRINT SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 5430 DL	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 6100	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 6100DN	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 6100DP	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 6100EN	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 6100EP	Xerox Phaser 8860

Printer - Laser	QMS	MAGICOLOR 6100GN	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR 6100N	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR CX	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR CX/ 8	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR CX/ 20	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR CX/ 32	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR CX/ 40	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR CX/1200	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR LASER	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR LX	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR PLUS	Xerox Phaser 8860
Printer - Laser	QMS	MAGICOLOR WX	Xerox Phaser 8860
Printer - Laser	QMS	MAGNUM LP15	Xerox Phaser 8860
Printer - Laser	QMS	PAGEPRO 1100	Xerox Phaser 8860
Printer - Laser	QMS	PAGEPRO 1100L	Xerox Phaser 8860
Printer - Laser	QMS	PAGEPRO 1350W	Xerox Phaser 8860
Printer - Laser	QMS	PAGEPRO 4100 W	Xerox Phaser 8860
Printer - Laser	QMS	PAGEPRO 4100E	Xerox Phaser 8860
Printer - Laser	QMS	PAGEPRO 4100GN	Xerox Phaser 8860
Printer - Laser	QMS	PAGEPRO 4110W	Xerox Phaser 8860
Printer - Laser	QMS	PAGEWORKS	Xerox Phaser 8860
Printer - Laser	QMS	PAGEWORKS 18 +	Xerox Phaser 8860
Printer - Laser	QMS	PAGEWORKS 18 PRINT SYSTEM	Xerox Phaser 8860
Printer - Laser	QMS	PAGEWORKS 18LN	Xerox Phaser 8860
Printer - Laser	QMS	PAGEWORKS 18N	Xerox Phaser 8860
Printer - Laser	QMS	PAGEWORKS 20	Xerox Phaser 8860
Printer - Laser	QMS	PAGEWORKS 8	Xerox Phaser 8860
Printer - Laser	QMS	PAGEWORKS 8 L	Xerox Phaser 8860
Printer - Laser	QMS	PAGEWORKS 8 N	Xerox Phaser 8860

Printer - Laser	QMS	PRINTLINK II	Xerox Phaser 8860
Printer - Laser	QMS	PS	Xerox Phaser 8860
Printer - Laser	QMS	PS 1500	Xerox Phaser 8860
Printer - Laser	QMS	PS 1700	Xerox Phaser 8860
Printer - Laser	QMS	PS 2000	Xerox Phaser 8860
Printer - Laser	QMS	PS 2200	Xerox Phaser 8860
Printer - Laser	QMS	PS 2210	Xerox Phaser 8860
Printer - Laser	QMS	PS 2220	Xerox Phaser 8860
Printer - Laser	QMS	PS 2400	Xerox Phaser 8860
Printer - Laser	QMS	PS 2700	Xerox Phaser 8860
Printer - Laser	QMS	PS 3200	Xerox Phaser 8860
Printer - Laser	QMS	PS 410	Xerox Phaser 8860
Printer - Laser	QMS	PS 420	Xerox Phaser 8860
Printer - Laser	QMS	PS 800	Xerox Phaser 8860
Printer - Laser	QMS	PS 800 II	Xerox Phaser 8860
Printer - Laser	QMS	PS 800 PLUS	Xerox Phaser 8860
Printer - Laser	QMS	PS 810	Xerox Phaser 8860
Printer - Laser	QMS	PS 810 TURBO	Xerox Phaser 8860
Printer - Laser	QMS	PS 815	Xerox Phaser 8860
Printer - Laser	QMS	PS 815 MR	Xerox Phaser 8860
Printer - Laser	QMS	PS 820	Xerox Phaser 8860
Printer - Laser	QMS	PS 820 TURBO	Xerox Phaser 8860
Printer - Laser	QMS	PS 825	Xerox Phaser 8860
Printer - Laser	QMS	PS 825 MR	Xerox Phaser 8860
Printer - Laser	QMS	PS JET	Xerox Phaser 8860
Printer - Laser	QMS	PS JET PLUS	Xerox Phaser 8860
Printer - Laser	QMS	QMS/Minolta/Konica 2200	Xerox Phaser 8860
Printer - Laser	QMS	SMARTWRITER	Xerox Phaser 8860
Printer - Laser	QMS	SMARTWRITER 150	Xerox Phaser 8860

Printer - Laser	QMS	SMARTWRITER 8/3X	Xerox Phaser 8860
Printer - Laser	QMS	SMARTWRITER 80+	Xerox Phaser 8860
Printer - Laser	QMS	ULTRASCRIPT MAC	Xerox Phaser 8860
Printer - Laser	QMS	ULTRASCRIPT PC	Xerox Phaser 8860
Printer - Laser	QMS	WEDGEBOX	Xerox Phaser 8860
Printer - Laser	RICOH	Aficio CL3500n	Xerox Phaser 8860
Printer - Laser	RICOH	Aficio CL4000dn	Xerox Phaser 8860
Printer - Laser	RICOH	Aficio SPC410dn	Xerox Phaser 8860
Printer - Laser	RICOH	AP1400	Xerox Phaser 8860
Printer - Laser	RICOH	AP2000	Xerox Phaser 8860
Printer - Laser	RICOH	AP204	Xerox Phaser 8860
Printer - Laser	RICOH	AP206	Xerox Phaser 8860
Printer - Laser	RICOH	AP2100	Xerox Phaser 8860
Printer - Laser	RICOH	AP2600	Xerox Phaser 8860
Printer - Laser	RICOH	AP2600N	Xerox Phaser 8860
Printer - Laser	RICOH	AP2610	Xerox Phaser 8860
Printer - Laser	RICOH	AP2610N	Xerox Phaser 8860
Printer - Laser	RICOH	AP2700	Xerox Phaser 8860
Printer - Laser	RICOH	AP305	Xerox Phaser 8860
Printer - Laser	RICOH	AP306	Xerox Phaser 8860
Printer - Laser	RICOH	AP306D	Xerox Phaser 8860
Printer - Laser	RICOH	AP3200	Xerox Phaser 8860
Printer - Laser	RICOH	AP3800C	Xerox Phaser 8860
Printer - Laser	RICOH	AP3800D	Xerox Phaser 8860
Printer - Laser	RICOH	AP3800DL	Xerox Phaser 8860
Printer - Laser	RICOH	AP3800DT1	Xerox Phaser 8860
Printer - Laser	RICOH	AP3800DT2	Xerox Phaser 8860
Printer - Laser	RICOH	AP3850	Xerox Phaser 8860
Printer - Laser	RICOH	AP400	Xerox Phaser 8860

Printer - Laser	RICOH	AP400N	Xerox Phaser 8860
Printer - Laser	RICOH	AP410	Xerox Phaser 8860
Printer - Laser	RICOH	AP410N	Xerox Phaser 8860
Printer - Laser	RICOH	AP4500	Xerox Phaser 8860
Printer - Laser	RICOH	AP4510	Xerox Phaser 8860
Printer - Laser	RICOH	AP505	Xerox Phaser 8860
Printer - Laser	RICOH	AP600	Xerox Phaser 8860
Printer - Laser	RICOH	AP600N	Xerox Phaser 8860
Printer - Laser	RICOH	AP610	Xerox Phaser 8860
Printer - Laser	RICOH	AP610N	Xerox Phaser 8860
Printer - Laser	RICOH	CL 1000N	Xerox Phaser 8860
Printer - Laser	RICOH	CL1000	Xerox Phaser 8860
Printer - Laser	RICOH	CL2000	Xerox Phaser 8860
Printer - Laser	RICOH	CL2000N	Xerox Phaser 8860
Printer - Laser	RICOH	CL3000	Xerox Phaser 8860
Printer - Laser	RICOH	CL3000E	Xerox Phaser 8860
Printer - Laser	RICOH	CL4000DN	Xerox Phaser 8860
Printer - Laser	RICOH	CL5000	Xerox Phaser 8860
Printer - Laser	RICOH	CL7000	Xerox Phaser 8860
Printer - Laser	RICOH	CL7000D	Xerox Phaser 8860
Printer - Laser	RICOH	CL7000DL	Xerox Phaser 8860
Printer - Laser	RICOH	CL7000DT1	Xerox Phaser 8860
Printer - Laser	RICOH	CL7000DT2	Xerox Phaser 8860
Printer - Laser	RICOH	CL7100	Xerox Phaser 8860
Printer - Laser	RICOH	CL7100D	Xerox Phaser 8860
Printer - Laser	RICOH	CL7100DL	Xerox Phaser 8860
Printer - Laser	RICOH	CL7100DT1	Xerox Phaser 8860
Printer - Laser	RICOH	CL7100DT2	Xerox Phaser 8860
Printer - Laser	SAMSUNG	CLP-500DN	Xerox Phaser 8860

Printer - Laser	SAMSUNG	CLP-510	Xerox Phaser 8860
Printer - Laser	SAMSUNG	CLP-550N	Xerox Phaser 8860
Printer - Laser	SAMSUNG	ML-1610	Xerox Phaser 8860
Printer - Laser	SAMSUNG	ML1710	Xerox Phaser 8860
Printer - Laser	SAMSUNG	ML1740	Xerox Phaser 8860
Printer - Laser	SAMSUNG	ML2010	Xerox Phaser 8860
Printer - Laser	SAMSUNG	ML6060	Xerox Phaser 8860
Printer - Laser	SAMSUNG	QL-7050N	Xerox Phaser 8860
Printer - Laser	XEROX	Phaser 3150	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	_4011	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	_4050	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	_4197	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	_4213	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	_4235	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	_4520	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	_4692	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	_4693	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	_4696	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	_4700	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	_8808	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	4030 II	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	4045 LASER CP MODEL 120	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	4045 LASER CP MODEL 150	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	4045 MODEL 160	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	4197 MICR	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	4197 MICR II	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	4213 II	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	4215 MICR	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	4215 MRP	Xerox Phaser 8860

Printer - Laser	XEROX/TEKTRONIX	4219 MRP	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	4220 MRP	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	4220 NETWORK PRINTER	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	4230 MRP	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	4520MP	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	4700 II	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	4850	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	COLOR LASER PRINTER	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	COLORQUICK	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUCOLOR 4CP	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUCOLOR 4LP	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUCOLOR 12	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUCOLOR 2006DPC	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUCOLOR 2006NPC	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUMENT CENTRE 35	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT 184HC PPS	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT 4232	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT 4505	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT 4505PS	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT 4508	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT 4510	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT 4510PS	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT 4512	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT 4512N	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT 4517	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT 4517MP	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT 4525	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT 4525CN	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT 4525DX	Xerox Phaser 8860

Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT C55	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT C55MP	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT M750	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT M760	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N17	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N17B	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N2025	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N2025TD	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N2125B	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N2125DT	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N2125DX	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N2125N	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N24	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N24FN	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N24HD	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N2825	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N2825DT	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N2825DX	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N2825TD	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N32	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N3225	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N3225CN	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N3225FN	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N3225HD	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N32CN	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N32FN	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N40	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N4025	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N4025FN	Xerox Phaser 8860

Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N40CN	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N40FN	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N40HD	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N4524DP	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N4525	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N4525CN	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N4525DP	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N4525DX	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT N4525FN	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT NC60	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT P12	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT P1202	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT P1210	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT P8	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT P8E	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	DOCUPRINT P8EX	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 1235	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 1235DT	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 1235DX	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 1235N	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 140	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 200E	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 200I	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 2135DT	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 2135DX	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 2135N	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 220E	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 220I	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 240	Xerox Phaser 8860

Printer - Laser	XEROX/TEKTRONIX	PHASER 300I	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 300X	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	Phaser 3130	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	Phaser 3150B	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 340	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 3400 B	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 3400 N	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	Phaser 3450D	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	Phaser 3450DN	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 350	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	Phaser 3500B	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 3500DN	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	Phaser 3500N	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 360	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 380	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 440	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	Phaser 4400B	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 4400N	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 450	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	Phaser 4500B	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	Phaser 4500DT	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	Phaser 4500N	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 480/X	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 540	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 540+	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 5400DT	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 5400N	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 550	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 5500	Xerox Phaser 8860

Printer - Laser	XEROX/TEKTRONIX	PHASER 5500DT	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 560	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 560 EXT	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 600	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 6100	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 6100	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 6200	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 6200DP	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 6200DX	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 6250	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 7300	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 740	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 740 COLOR	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 740 DUPL	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 740 EXTD	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 740L	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 740N	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 740P	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 750	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 750DP	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 750DX	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 750N	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 750P	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 7700	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 7750DXF	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 780	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 780GN	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 780P	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 790	Xerox Phaser 8860

Printer - Laser	XEROX/TEKTRONIX	PHASER 790DP	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 790N	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 8200DP	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 8200DX	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 8400N	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 840DP	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 840DX	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 840GP	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 840N	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 850	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 850DP	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 850DX	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 850N	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 860	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 860B	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 860DP	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 860DX	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER 860N	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER COPYSTATION	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER II	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER II PXI	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER II SDX	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER III PXI	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER LAMINATOR	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER Z850DP	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	PHASER Z850N	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	REGAL 5790	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	RGB 3	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	RGB/RGB2	Xerox Phaser 8860

Printer - Laser	XEROX/TEKTRONIX	VIVIGRAF X XL	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	XPRINT 4900	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	XPRINT 4915	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	XPRINT 4915 PLUS	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	XPRINT 4920	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	XPRINT 4920 PLUS	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	XPRINT 4925	Xerox Phaser 8860
Printer - Laser	XEROX/TEKTRONIX	XPRINT 4925 PLUS	Xerox Phaser 8860