

Customer Tips

dc04cc0330
June 16, 2006

... for the user

Xerox Walk-Up Print Driver

Purpose

This document describes the features of the Xerox Walk-Up Printing Driver that connects you to a PostScript printer. The driver eliminates the need for multiple PostScript drivers.

Note: In addition to the Document Centres, WorkCentres, and WorkCentre Pros listed in the product box, the Walk-up Printing Driver is available for these Xerox devices:

- Phaser 8550, 8500, 8400, 8200, 7760, 7750, 7700, 7400, 7300, 6350, 6300, 6250, 6200, 6120, 5500, 5400, 4500, 4400, 3450, 3400, 2135, 1235, 860, 850, 840, 790, 780, 750, 740L, 740
- DocuColor 2006
- DocuPrint N4525, N4025, N3225, N2825, N2125, N2125b, N2025, N40, N24, N32
- WorkCentre C2424

Check the documentation provided with your device for information about Phaser, DocuColor, DocuPrint and WorkCentre support groups.

Description

The Xerox Walk-Up Printing Driver is designed for individuals who travel between offices and use a variety of print devices. The driver stores access information for up to 15 printers. You can connect to a PostScript printer using one of the methods the Walk-up Printing Driver offers.

- Enter an IP address, DNS name, or print queue path.
- Browse for a print queue.
- Parallel or USB port.

Note: The selection **Use Walk-up Technology** is not available for Document Centre, WorkCentre, or WorkCentre Pro devices.

The Xerox Walk-Up Printing Driver offers a feature set common to most PostScript printers:

1. Orientation: portrait, landscape and rotated landscape
2. Duplex: flip on long or short edge
3. N-Up: 1, 2, 4, 6, 9, 16
4. Booklet mode
5. Media Types: plain paper, transparency
6. Media sizes: see driver for selections

This document applies to the **Xerox** products indicated in the table below. For some products, it is assumed that your device is equipped with the appropriate option to support this document.

x	WC 7655/7665
x	WC Pro 232/238/245/255/265/275
x	WC 232/238/245/255/265/275
x	WC Pro C2128/C2636/C3545
x	WC Pro 165/175
x	WC M165/M175
x	WC Pro 32/40 Color
x	WC Pro 65/75/90
x	WC Pro 35/45/55
x	WC M35/M45/M55
x	DC 555/545/535
x	DC 490/480/470/460
x	DC 440/432/425/420

Downloading the Xerox Walk-Up Printing Driver

1. Access the Xerox.com home page.
2. Select **Support and Drivers**.
3. Search for a device that supports the Walk-Up Printing Driver or use the product type selections to locate a device that is supported. Select **Drivers & Downloads**.

United States [Change Country](#) > [Products A-Z Index](#)

XEROX Support & Drivers

Where to Buy | Contact Us | Log In/My Xerox | Account Management | Shopping Cart

Office Equipment | Production Equipment | Services & Outsourcing | Supplies | Support & Drivers

Enter product name or number
For example: Phaser 8200, 8400, DocuColor 12

[Which product do I have?](#)

OR, Select product below

1. Select Product Type

- > Color Printers
- > Black & White Printers
- > **Multifunction**
- > Color Copiers
- > Black & White Copiers
- > Fax Machines
- > Production Systems
- > Software & Platforms
- > Wide Format
- > Scanners & Peripherals

[A-Z List of all products](#)

2. Select Product Family

- > 4110/4590
- > digital BookMark
- > DocuColor
- > Document Centre
- > FaxCentre
- > WorkCentre
- > **WorkCentre Pro**
- > Other

3. Select Model


- WorkCentre Pro 265/275 [Support](#) | [Drivers & Downloads](#) | [Documentation](#)
- WorkCentre Pro 412 [Support](#) | [Drivers & Downloads](#) | [Documentation](#)
- WorkCentre Pro 416DE [Support](#) | [Drivers & Downloads](#) | [Documentation](#)
- WorkCentre Pro 416 Si [Support](#) | [Drivers & Downloads](#) | [Documentation](#)

Xerox earns J.D. Power and Associates Service and Support award.
"An Outstanding Customer Service Experience"

4. For the Operating System select **Windows XP, Windows 2000, or Windows Server 2003** and click **Go**.
5. When the driver list appears, select the **Walk-Up Printing Driver**.
6. Follow the instructions to download the driver (a .exe file).
7. Open the downloaded Walk-Up Printing Driver .exe file, and follow the instructions to install the driver.
8. After the Walk-Up Printing Driver is installed you can access it in applications like any other driver.

Accessing the User Manual

A user manual in PDF format is included with the Walk-Up Printing Driver. This manual details all setup and use information about the driver. To access the manual from an application:

1. Select **Print**, then in the **Name** field select **Xerox Walk-Up Printing Driver 2.0**.
2. Click **OK** and select the bubble .

To access the manual from your desktop:

Select **Start>Programs>Xerox Walk-Up Printing Driver 2.0>Using the Xerox Walk-Up Printing Driver 2.0**.

Additional Information

Xerox Customer Support welcomes feedback on all documentation - send feedback via e-mail to: USA.DSSC.Doc.Feedback@mc.usa.xerox.com.

You can reach Xerox Customer Support at 1-800-821-2797 (USA), TTY 1-800-855-2880 or at <http://www.xerox.com>.

Other Tips about Xerox multifunction devices are available at the following URL: <http://www.office.xerox.com/support/dctips/dctips.html>.

XEROX®, The Document Company®, the digital X®, and all Xerox product names are trademarks of XEROX CORPORATION. Other trademarks belong to their respective owners.

Copyright © XEROX CORPORATION 2006. All Rights Reserved.

XEROX®