

Xerox[®] Product Compatibility

macOS[®] Sonoma

At Xerox, we offer a wide variety of print drivers for the newest operating system from Apple — macOS[®] Sonoma. The following table lists various Xerox[®] Office and Light Production products and information regarding Xerox[®] Driver compatibility and availability. The table refers to the compatibility level for each product. It will be updated periodically as Xerox releases new macOS[®] Sonoma-compatible device drivers.

Note: Support is provided for the current release of macOS[®] Sonoma 14.x and the preceding two versions of macOS (13.x and 12.x) with our latest driver.

To access the latest information for printer drivers for your products, visit www.xerox.com/drivers, enter the name of your product, and select the Drivers and Downloads link from the resulting page.

COMPATIBILITY LEVELS

COMPATIBILITY LEVEL	DESCRIPTION
1	Drivers for macOS [®] Sonoma are available and can be downloaded from www.support.xerox.com .
2	This product does not have support for macOS [®] Sonoma.
3	Delivery of updated drivers for macOS [®] Sonoma is currently being evaluated for this product. Please continue to visit www.support.xerox.com for updates regarding our driver delivery plans.
4	Drivers developed for previous Apple OS versions may be compatible. Refer to the Additional Information section for your specific device.
5	To locate drivers for Fiery [®] Digital Print Servers or another Digital Front End, please visit www.support.xerox.com . Choose your device type and select the appropriate Digital Front End from the filters section. Additional drivers may also be available for download from the EFI [®] Download Center at www.efi.com/support-and-downloads/download-center .

If your desired product does not indicate a print driver provided by Xerox, go to <https://www.support.xerox.com/en-us/article/en/2120800> for more information on utilizing the macOS native capability to print using AirPrint[™].

XEROX DEVICES	COMPATIBILITY LEVEL	ADDITIONAL INFORMATION
Xerox[®] Printers and Multifunction Printers		
Xerox [®] AltaLink [®] B8045/B8055/B8065/B8075/B8090 Multifunction Printer	<u>1</u>	
Xerox [®] AltaLink [®] C8030/C8035/C8045/C8055/C8070 Color Multifunction Printer	<u>1</u>	
Xerox [®] AltaLink [®] B8145/B8155/B8170 Multifunction Printer	<u>1</u>	
Xerox [®] AltaLink [®] C8130/C8135/C8145/C8155/C8170 Color Multifunction Printer	<u>1</u>	
EFI [®] Fiery [®] Controller-Xerox [®] EX-c C8100 Print Server	<u>5</u>	
EFI [®] Fiery [®] Controller-Xerox [®] EX-c C8000 Print Server	<u>5</u>	
Xerox [®] B210 Printer	<u>4</u>	See https://www.support.xerox.com/en-us/product/xerox-b210-printer/downloads for latest drivers. This product can utilize AirPrint [™] to enable printing from macOS.
Xerox [®] B205 Multifunction Printer	<u>4</u>	See https://www.support.xerox.com/en-us/product/xerox-b205-multifunction-printer/downloads for latest drivers. This product can utilize AirPrint [™] to enable printing from macOS.

Xerox® Product Compatibility

macOS® Sonoma

Xerox® B215 Multifunction Printer	<u>4</u>	See https://www.support.xerox.com/en-us/product/xerox-b215-multifunction-printer/downloads for latest drivers. This product can utilize AirPrint™ to enable printing from macOS.
Xerox® B225 Multifunction Printer	<u>1</u>	
Xerox® B230 Printer	<u>1</u>	
Xerox® B235 Multifunction Printer	<u>1</u>	
Xerox® B305 Multifunction Printer	<u>1</u>	
Xerox® B310 Printer	<u>1</u>	
Xerox® B315 Multifunction Printer	<u>1</u>	
Xerox® B410 Printer	<u>1</u>	
Xerox® B1022 Multifunction Printer	<u>1</u>	
Xerox® B1025 Multifunction Printer	<u>1</u>	
Xerox® C230 Color Printer	<u>1</u>	
Xerox® C235 Color Multifunction Printer	<u>1</u>	
Xerox® C310 Color Printer	<u>1</u>	
Xerox® C315 Color Multifunction Printer	<u>1</u>	
Xerox® C410 Color Printer	<u>1</u>	
Xerox® ColorQube® 8570 Printer	<u>2</u>	
Xerox® ColorQube® 8580 Color Printer	<u>4</u>	See https://www.support.xerox.com/en-us/product/colorqube-8580/downloads for latest drivers.
Xerox® ColorQube® 8700 Color Multifunction Printer	<u>4</u>	See https://www.support.xerox.com/en-us/product/colorqube-8700/downloads for latest drivers.
Xerox® ColorQube® 8870 Printer	<u>2</u>	
Xerox® ColorQube® 8880 Color Printer	<u>4</u>	
Xerox® ColorQube® 8900 Multifunction Printer	<u>4</u>	See https://www.support.xerox.com/en-us/product/colorqube-8900/downloads for latest drivers.
Xerox® ColorQube® 9201/9202/9203 Multifunction Printer	<u>2</u>	See https://www.support.xerox.com/en-us/product/colorqube-9201-9202-9203/downloads for latest drivers.
Xerox® ColorQube® 9301/9302/9303 Multifunction Printer	<u>4</u>	See https://www.support.xerox.com/en-us/product/colorqube-9300-series/downloads for latest drivers.
Xerox® EC8036 Color Multifunction Printer	<u>1</u>	
Xerox® EC8056 Color Multifunction Printer	<u>1</u>	
Xerox® Phaser® 3010 Printer	<u>2</u>	
Xerox® Phaser® 3020 Printer	<u>4</u>	See https://www.support.xerox.com/en-us/product/phaser-3020/downloads for latest drivers. This product can utilize AirPrint™ to enable printing from macOS.
Xerox® Phaser® 3040 Printer	<u>2</u>	
Xerox® Phaser® 3052 Printer	<u>4</u>	See https://www.support.xerox.com/en-us/product/phaser-3052/downloads for latest drivers. This product can utilize AirPrint™ to enable printing from macOS.

Xerox® Product Compatibility

macOS® Sonoma

Xerox® Phaser® 3250 Printer	<u>2</u>	
Xerox® Phaser® 3260 Printer	<u>4</u>	See https://www.support.xerox.com/en-us/product/phaser-3260/downloads for latest drivers. This product can utilize AirPrint™ to enable printing from macOS.
Xerox® Phaser® 3320 Printer	<u>2</u>	
Xerox® Phaser® 3330 Printer	<u>1</u>	
Xerox® Phaser® 3610 Printer	<u>1</u>	
Xerox® Phaser® 3635 Multifunction Printer	<u>2</u>	
Xerox® Phaser® 4622 Printer	<u>1</u>	
Xerox® Phaser® 6000 Printer	<u>2</u>	
Xerox® Phaser® 6010 Printer	<u>2</u>	
Xerox® Phaser® 6015 Multifunction Printer	<u>2</u>	
Xerox® Phaser® 6020 Color Printer	<u>4</u>	See https://www.support.xerox.com/en-us/product/phaser-6020/downloads for latest drivers. This product can utilize AirPrint™ to enable printing from macOS.
Xerox® Phaser® 6022 Color Printer	<u>4</u>	See https://www.support.xerox.com/en-us/product/phaser-6022/downloads for latest drivers. This product can utilize AirPrint™ to enable printing from macOS.
Xerox® Phaser® 6400 Multifunction Printer	<u>4</u>	See https://www.support.xerox.com/en-us/product/workcentre-6400/downloads for latest drivers.
Xerox® Phaser® 6500 Color Printer	<u>2</u>	
Xerox® Phaser® 6510 Color Printer	<u>1</u>	
Xerox® Phaser® 6600 Color Printer	<u>1</u>	
Xerox® Phaser® 6700 Color Printer	<u>1</u>	
Xerox® Phaser® 7100 Color Printer	<u>4</u>	See https://www.support.xerox.com/en-us/product/phaser-7100/downloads for latest drivers.
Xerox® Phaser® 7500 Color Printer	<u>1</u>	
Xerox® Phaser® 7800 Color Printer	<u>1</u>	
Xerox® VersaLink® B400 Printer	<u>1</u>	
Xerox® VersaLink® B405 Multifunction Printer	<u>1</u>	
Xerox® VersaLink® B415 Multifunction Printer	<u>1</u>	
Xerox® VersaLink® B600/B610 Printer	<u>1</u>	
Xerox® VersaLink® B605/B615 Multifunction Printer	<u>1</u>	
Xerox® VersaLink® B625 Multifunction Printer	<u>1</u>	
Xerox® VersaLink® C400 Color Printer	<u>1</u>	
Xerox® VersaLink® C405 Color Multifunction Printer	<u>1</u>	
Xerox® VersaLink® C415 Color Multifunction Printer	<u>1</u>	
Xerox® VersaLink® C500 Color Printer	<u>1</u>	
Xerox® VersaLink® C505 Color Multifunction Printer	<u>1</u>	
Xerox® VersaLink® C600 Color Printer	<u>1</u>	
Xerox® VersaLink® C605 Color Multifunction Printer	<u>1</u>	

Xerox[®] Product Compatibility

macOS[®] Sonoma

Xerox [®] VersaLink [®] C625 Color Multifunction Printer	<u>1</u>	
Xerox [®] VersaLink [®] B7025/B7030/B7035 Multifunction Printer	<u>1</u>	
Xerox [®] VersaLink [®] C7000 Color Printer	<u>1</u>	
Xerox [®] VersaLink [®] C7020/C7025/C7030 Color Multifunction Printer	<u>1</u>	
Xerox [®] VersaLink [®] C8000/C9000 Color Printer	<u>1</u>	
Xerox [®] VersaLink [®] C8000W Color Printer	<u>1</u>	
Xerox [®] WorkCentre [®] 3025 Multifunction Printer	<u>4</u>	See https://www.support.xerox.com/en-us/product/workcentre-3025/downloads for latest drivers. This product can utilize AirPrint™ to enable printing from macOS.
Xerox [®] WorkCentre [®] 3045 Multifunction Printer	<u>2</u>	
Xerox [®] WorkCentre [®] 3215 Multifunction Printer	<u>4</u>	See https://www.support.xerox.com/en-us/product/workcentre-3215/downloads for latest drivers. This product can utilize AirPrint™ to enable printing from macOS.
Xerox [®] WorkCentre [®] 3225 Multifunction Printer	<u>4</u>	See https://www.support.xerox.com/en-us/product/workcentre-3225/downloads for latest drivers. This product can utilize AirPrint™ to enable printing from macOS.
Xerox [®] WorkCentre [®] 3315/3325 Multifunction Printer	<u>2</u>	
Xerox [®] WorkCentre [®] 3335/3345 Multifunction Printer	<u>1</u>	
Xerox [®] WorkCentre [®] 3615 Multifunction Printer	<u>1</u>	
Xerox [®] WorkCentre [®] 3655 Multifunction Printer	<u>1</u>	
Xerox [®] WorkCentre [®] 3655i Multifunction Printer	<u>1</u>	
Xerox [®] WorkCentre [®] 4250 Multifunction Printer	<u>2</u>	
Xerox [®] WorkCentre [®] 4260 Multifunction Printer	<u>2</u>	
Xerox [®] WorkCentre [®] 4265 Multifunction Printer	<u>4</u>	See https://www.support.xerox.com/en-us/product/workcentre-4265/downloads for latest drivers.
Xerox [®] WorkCentre [®] 5135/5150 Multifunction Printer	<u>2</u>	
Xerox [®] WorkCentre [®] 5222/5225/5230 Multifunction Printer	<u>2</u>	
Xerox [®] WorkCentre [®] 5325/5330/5335 Multifunction Printer	<u>1</u>	
Xerox [®] WorkCentre [®] 5735/5740/5745/5755/5765/5775/5790 Multifunction Printer	<u>1</u>	
Xerox [®] WorkCentre [®] 5845/5855/5865/5875/5890 Multifunction Printer	<u>1</u>	
Xerox [®] WorkCentre [®] 5865i/5875i/5890i Multifunction Printer	<u>1</u>	
Xerox [®] WorkCentre [®] 5945/5955 Multifunction Printer	<u>1</u>	
Xerox [®] WorkCentre [®] 5945i/5955i Multifunction Printer	<u>1</u>	
Xerox [®] WorkCentre [®] 6025 Color Multifunction Printer	<u>4</u>	See https://www.support.xerox.com/en-us/product/workcentre-6025/downloads for latest drivers. This product can utilize AirPrint™ to enable printing from macOS.

Xerox® Product Compatibility

macOS® Sonoma

Xerox® WorkCentre® 6027 Color Multifunction Printer	4	See https://www.support.xerox.com/en-us/product/workcentre-6027/downloads for latest drivers. This product can utilize AirPrint™ to enable printing from macOS.
Xerox® WorkCentre® 6505 Color Multifunction Printer	2	
Xerox® WorkCentre® 6515 Color Multifunction Printer	1	
Xerox® WorkCentre® 6605 Color Multifunction Printer	2	
Xerox® WorkCentre® 6655 Color Multifunction Printer	1	
Xerox® WorkCentre® 6655i Color Multifunction Printer	1	
Xerox® WorkCentre® 7120/7125 Multifunction Printer	2	
Xerox® WorkCentre® 7220/7225 Multifunction Printer	1	
Xerox® WorkCentre® 7220i/7225i Color Multifunction Printer	1	
Xerox® WorkCentre® 7328/7335/7345/7346 Multifunction Printer Built-in Controller	2	
EFI® Fiery® Controller	5	
Xerox® WorkCentre® 7425/7428/7435 Multifunction Printer Built-in Controller	2	
EFI® Fiery® Controller	5	
Xerox® WorkCentre® 7525/7530/7535/7545/7556 Color Multifunction Printer Built-in Controller	1	
EFI® Fiery® Controller	5	
Xerox® WorkCentre® 7755/7765/7775 Multifunction Printer Built-in Controller	2	
EFI® Fiery® Controller	5	
Xerox® WorkCentre® 7830/7835/7845/7855 Color Multifunction Printer	1	
EFI® Fiery® Network Server	5	
Xerox® WorkCentre® 7830i/7835i/7845i/7855i Color Multifunction Printer	1	
EFI® Fiery® Network Server	5	
Xerox® WorkCentre® 7970 Color Multifunction Printer	1	
Xerox® WorkCentre® 7970i Color Multifunction Printer	1	
EFI® Fiery® Network Server	5	
Xerox® WorkCentre® EC7836/EC7856 Multifunction Printer	1	
ENTRY PRODUCTION COLOR PRODUCTS		
Xerox® Color C75 Press Xerox® FreeFlow® Print Server	4	See https://www.support.xerox.com/en-us/product/xerox-c75/downloads for latest drivers.
Integrated Fiery® Color Server	5	
Xerox® EX Print Server (powered by Fiery®)	5	
Xerox® Color J75 Press Xerox® FreeFlow® Print Server	4	See https://www.support.xerox.com/en-us/product/xerox-j75/downloads for latest drivers.
Xerox® EX Print Server (powered by Fiery®)	5	
Xerox® Color C60/C70 Printer Built-in Controller	1	

Xerox® Product Compatibility

macOS® Sonoma

Xerox® FreeFlow® Print Server	<u>1</u>	
Integrated Fiery® EX-i Color Server	<u>5</u>	
Xerox® EX Print Server (powered by Fiery®)	<u>5</u>	
Xerox® Color EC70 Printer Built-in Controller	<u>1</u>	Use driver for Xerox® Color C60/C70 Printer Integrated Color Server
Xerox® EX-i C60/C70 Print Server for EC70	<u>5</u>	
Xerox® PrimeLink® C9065/C9070 Printer Built-in Controller	<u>1</u>	
Xerox® EX C9065/C9070 Print Server (powered by Fiery®)	<u>5</u>	
Xerox® EX-i C9065/C9070 Print Server (powered by Fiery®)	<u>5</u>	
Xerox® EX-c C9065/C9070 Print Server (powered by Fiery®)	<u>5</u>	
LIGHT PRODUCTION MONOCHROME PRODUCTS		
Xerox® D95/D95A/D110/D125 Copier/Printer Xerox® FreeFlow® Print Server	<u>1</u>	
Built-in Controller	<u>1</u>	
Xerox® EX Print Server (powered by Fiery®)	<u>5</u>	
Xerox® ED95A/ED125 Copier/Printer Built-in Controller	<u>1</u>	Use driver for Xerox® D95/D110/D125 Copier/Printer built-in controller
Xerox® EX II Print Server for ED95A/ED125	<u>5</u>	
Xerox® D136 Copier/Printer Xerox® FreeFlow® Print Server	<u>1</u>	
Built-in Controller	<u>1</u>	
Xerox® EX Print Server (powered by Fiery®)	<u>5</u>	
Xerox® PrimeLink® B9100/B9110/B9125/B9136 Copier/Printer Integrated Server (supported)	<u>1</u>	
Xerox® EX Print Server (powered by Fiery®)	<u>5</u>	

Xerox® Product Compatibility

macOS® Sonoma

XEROX SUPPORT CONTACT INFORMATION

For additional information or clarification for any of the product information presented in this document, please contact your local Xerox Customer Support Center, Xerox Customer Support at 1-800-821-2797 (U.S.), TTY 1-800-855-2880, or visit www.support.xerox.com.